



MHSC reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

Defiant Woodburning Stove

Model 1610

Defiant Woodburning Stove Model 1610 (continued)

Item Description	Part Number	Item Description	Part Number
1. Side Insulation	30002846	52. Door Latch Assy	5004025
2. Right Side Brick	30002847	53. Ashdoor	30002810
3. Left Side Refractory	30002848	54. Ashdoor Handle (Wood)	1600663
4. Brick Support Bracket	30002480	55. Ashdoor Hinge Rod	30002826
5. Griddle Gasket	1203668	56. Cotter Pin, Ashdoor	30001749
6. Back	30002833	57. Ashdoor Bottom Hinge Support	1300642
7. Left Heat Deflector	30002442	58. Ashpan Bracket	30001908
8. Right Heat Deflector	30002441	59. Primary Air Flap	30002849
9. Shoe Refractory	30002243	60. Primary Air Shaft	30002841
10. Shoe Gasket	30002864	61. Air Linkage	30002842
11. Fireback	30002840	62. Rear Side Bracket	30002845
12. Outer Back	30002839	63. Thermostat Handle	1600660
13. Left Griddle Quadrant	30002399	64. Airwash Manifold	30002814
14. Right Griddle Quadrant	30002401	65. Front	See Chart Pg. 37
15. Griddle	30002822	66. Flue Collar Gasket	30001910
16. Griddle Handle	1600657	67. Left Door	See Chart Pg. 37
17. Griddle Handle Spacer	1600070	68. Door Hinge Strip	1300645
18. Griddle Handle Bolt	1200907	69. Top	See Chart Pg. 37
19. Damper Gasket	1203588	70. Glass Clip	30001715
20. Damper Ramp	1300643	71. Glass Clip (Right Door Only)	30001716
21. Damper Housing	30002821	72. Front Door Handle & Shaft	30002717
22. Damper ¹	30002816	73. Right Door	See Chart Pg. 37
23. Damper Tab ¹	1601488	74. Door Gasket	1203589
24. Damper Rod ¹	1600065	75. Glass Gasket	1203556
25. Griddle Handle Bushing	1201895	76. Left Door Glass ¹	1600064
26. Ash Door Heat Shield	1401911	77. Right Door Glass ¹	1600062
27. Rheostat Bracket	30002863	78. Lower Door Hinge Pin	30002727
28. Fountain Assembly	30002100	79. Spacer (for Damper rod)	1201779
29. Damper Handle Screw	1201310	80. Upper Door Hinge Pin	30002727
30. Damper Handle	1600644	81. Handle Base Stub	30002714
31. Damper Handle Base Assy	30002720	82. Wood Handle	1600664
32. Left Side	See Chart Pg. 37	83. Handle Bolt	1201310
33. Left Air Manifold	30002818	84. Thermostat Handle Bolt	1201243
34. Right Air Manifold	30002817	85. Ash Pan Assy	30001690
35. Right Side	See Chart Pg. 37	87. Flue Collar	See Chart Pg. 37
36. Thermostat Handle Base Assy	30002716	88. Leg	See Chart Pg. 37
37. Washer Damper Rod	1202560	91. Hex Head Jam Nut	1203290
38. Grate	30002820	92. Bottom Heat Shield	30002843
39. Inner Bottom	30002838		
40. Top Ashdoor Hinge	30002836		
41. Door Handle Bracket	30002844		
42. Bottom	30002829		
43. Ashlip	See Chart Pg. 37		
44. Fireback Retainer	30002815		
45. Friction Spring	1201846		
46. Washer Friction Spring/Therm Handle Linkage	1202471		
47. Air Plate	30002819		
48. Andiron	30002827		
49. Control Spacer	1201781		
50. Leg Leveller	1201745		
51. Ashdoor Handle Shaft	1600622		

NOTES:

In this diagram and throughout this manual, 'left' and 'right' mean as you face the stove.

When ordering parts, be sure to mention the stove's model number. When ordering external parts, be sure to specify color.

1. Not interchangeable, due to a heat-reflective coating on the room side of the glass.

The hardware in the Defiant is in standard sizes; most bolts are 1/4" diameter by 20 threads per inch. Most hardware stores can supply replacement hardware if you specify bolt diameter, number of threads per inch and length. Fasteners inside the firebox should be replaced with stainless steel for ease of future disassembly.

Defiant Woodburning Stove Model 1610 (continued)

Shell Enamel Parts - Defiant Model 1610							
Part Name	Classic	Biscuit	Bordeaux	Chestnut Brown	Ebony	Midnight Blue	Vermont Green
Top	30002834	30002874	30002915	30002926	30002894	30002884	30002937
Left Side	30002832	30002872	30002913	30002924	30002892	30002882	30002935
Right Side	30002831	30002871	30002912	30002923	30002891	30002881	30002934
Flue Collar	30001576	30002947	30002921	30002932	30002910	30001617	30002943
Front	30002830	30002873	30002914	30002925	30002893	30002883	30002936
Ashlip	30002811	30002870	30002911	30002922	30002890	30002880	30002933
Left Door Sub Assy	30002854*	30002879	30002920	30002931	30002899	30002889	30002942
Left Door	30002813	30002876	30002917	30002928	30002896	30002886	30002939
Right Door Sub Assy	30002853*	30002878	30002919	30002930	30002898	30002888	30002941
Right Door	30002812	30002875	30002916	30002927	30002895	30002885	30002938
Leg	30002835	30002877	30002918	30002929	30002897	30002887	30002940

*NOTE: Does not contain glass or glass gasket.