



0956

CFM Specialty Home Products reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

Encore Woodburning Stove Model 2550

Item Description	Part Number
1. Secondary Air Cover Plate	1601492
2. Secondary Air Probe Assy	1601489
3. Secondary Air Link II, ENC	1601486
4. Secondary Air Flap	1601490
5. Flue Collar (8")	See Chart Pg. 35
6. Back	See Chart Pg. 35

Item Description	Part Number
7. Left Heat Deflector	1608629
8. Right Heat Deflector	1608630
9. Refractory Assy w/Access Panel	1602510
10. Catalytic Combustor	1602505
11. Refractory Access Panel	1602511
14. Left Griddle Quad	1301807

Encore Woodburning Stove

Model 2550 (continued)

Item Description	Part Number
15. Right Griddle Quad	1301832
16. Griddle	1300797
17. Griddle Handle Assy	5004022
18. Top	See Chart Pg. 35
21. Wedge	1301810
22. Upper Firebrick ¹	1308644
23. Damper ¹	1308631
24. Damper Tabs (3) ¹	1601488
25. Damper Rod ¹	1600851
27. Combustion Throat Hood	1301145
28. Lower Fireback	1308646
30. Damper Handle Screw 1/4-20 x 3/8" NT	1201294
31. Damper Handle Wood	1600664
33. Steel Handle Stub	0004356
34. Left Side	See Chart Pg. 35
35. Left Air Plate (Inner side)	1308621
36. Right Air Plate (Inner side)	1308622
37. Right Side	See Chart Pg. 35
38. Thermostat Handle Assy	5004264
39. Thermostat Assy	5005470
40. Grate	1307434
41. Primary Air Tube Cover Plate	1308609
42. Primary Air Frame	1307411
Primary Air Valve Only	1301412
Primary Air Rod Only	1601493
43. Primary Air Regulatory System	5000337
44. Bottom	1308604
45. Ashlip	See Chart Pg. 35
50. Andiron (2)	1307419
51. Leg	See Chart Pg. 35
52. Leg Leveler	1201745
53. Ashdrop	1308603
54. Ashdoor Latch Pawl	1300515
55. Ashdoor	1308607
56. Ashdoor Handle (Wood)	1600663

Item Description	Part Number
57. Ashdoor Hinge Pin	1208608
58. Cotter Pin, Ashdoor	30001749
59. Ashdoor Hinge Support	1308605
60. Ashpan	1601025
61. Ashpan Bracket	1601039
62. Ashpan Cover	1601027
70. Airwash Manifold	1308615
71. Front II	See Chart Pg. 35
72. Left Door Air Manifold	1307403
73. Left Door	See Chart Pg. 35
74. Door Hinge Strip (2)	1308634
75. Right Door Air Manifold	1307404
77. Door Handle Assy w/Set Screw	30001759
78. Right Door II	See Chart Pg. 35
79. Door Gasket 5/16 Med. Density 6ND	1203588
80. Glass Gasket	1203556
81. Left Door Glass ²	1408630
82. Right Door Glass ²	1408629
83. Door Latch	1408628
84. Spacer 3/8 x 1-Z	1201779
85. Damper Ramp ¹	1301811
Socket Set Screw Adjuster	1200436
PH Flat Hd Screw	1200809
Hex Nuts	1203210
86. Handle Base Stub ³	1600650
87. Ceramic Handle 2.78 Lg ²	1600620
88. Handle Bolt ¹	1201294
89. Friction Spring	1201846
90. Primary Air Cable w/Clips	5005471
91. 7/16-20 x 1 Socket Set Screw	1200334
92. Washer	1202471
93. Pin, Long, Door	1600547

1. Included in #5008649 upper fireback assembly.
2. Not interchangeable, due to a heat-reflective coating on the room side of the panels.
3. Included in #0004342 ceramic handle assembly.

Shell Enamel Parts - Encore Model 2550

Part Name	Classic	Green	Moonlight	Sand	Red	Blue	Suede Brown
Top	1308618	2318618	2378618	1328618	2328618	1338618	30002526
Left Side	1308623	2318623	2378623	1328623	2328623	1338623	30002524
Right Side	1308619	2318619	2378619	1328619	2328619	1338619	30002523
Flue Collar	1304280	2314280	2374280	1324280	2324280	1334280	30002527
Front	1308635	2318635	2378635	1328635	2328635	1338635	30002522
Ashlip	1307406	2317406	2377406	1327406	2327406	1337406	30002520
Left Door Subassembly	5008648	30001150	30001345	30001146	30001144	30001148	30002531
Left Door Only	1308637	2318637	2378637	1328637	2328637	1338637	30002529
Right Door Subassembly	5008647	30001149	30001344	30001145	30001143	30001147	30002530
Right Door Only	1308636	2318636	2378636	1328636	2328636	1338636	30002528
Single Leg	1307427	2317427	2377427	1327427	2327427	1337427	30002521
Back	1308620	2318620	2378620	1328620	2328620	1338620	30002525